# THE FOLLOWING PAGE CONTAINS THE CONNECTION DETAILS

It is your responsibility to ensure that the transducer identification matches the connection details, including any RDP modification (T.M) references.

Please ensure that the transducer has not been modified or fitted with a cable or extension.

Particularly on DC-DC powered transducers, incorrect connection may cause IRREPERABLE DAMAGE to the transducer which is NOT COVERED BY WARRANTY

IF YOU ARE IN ANY DOUBT PLEASE CONTACT US



+12 to +20V Input

-12 to -20V Input

0V Common I/P. O/P

Instrument Ground

O/P 1 (Nom)

O/P 2 (Nom)

**Dual Supply** 

## DCTH SERIES (DC to DC LVDT)

#### INPUT CONNECTIONS

RED

BLUE

BLACK

SHIELD

+FS ---:

+5V +10V

0V +5V

-FS

0V

-5v

See Cal. Cert. for exact figures.

0

Single Supply *	
+24 to +40V Input	RED
Supply Negative	BLUE
Instrument Ground	SHIELD
* SUPPLY MUST BE FULLY FLOATING	L
OUTPUT COMMON FLOATS AT Vs/2	

# CE

#### OUTPUT CONNECTIONS

1.0-10V	YELLOW	
2. ±5V	GREEN	
COMMON	BLACK	

**NOTE :** If only Output 2 ( $\pm$ 5V) is required then the supply minimum can be  $\pm$ 10V (dual) or 20V (single).

### LOAD IMPEDANCE : OUTPUT 1 10k (min) at 24V supply.

2K (min.) at 30V and higher supply **OUTPUT 2** 2k (min.)

SUPPLY: Smooth d.c. voltage 30mA typical.

## INSULATE UNUSED OUTPUT INCORRECT CONNECTION OR EXCESSIVE SUPPLY VOLTAGE MAY CAUSE IRREPARABLE DAMAGE WHICH CAN INVALIDATE THE WARRANTY. CONTACT OUR SALES DEPARTMENT IF YOU REQUIRE ASSISTANCE.

RDP U.K. Tel 01902 457512 Fax 01902 452000



NOTE :

## MADE IN THE UNITED KINGDOM

Doc. Ref. WDUK1116 ISSUE 9 - 9 SEP 2014 RDP U.S.A. Tel 610 469 0850 Fax 610 469 0852