

THE FOLLOWING PAGE CONTAINS THE CONNECTION DETAILS

It is your responsibility to ensure that the transducer identification matches the connection details, including any RDP modification (T.M) references.

Please ensure that the transducer has not been modified or fitted with a cable or extension.

Particularly on DC-DC powered transducers, incorrect connection may cause **IRREPERABLE DAMAGE** to the transducer which is **NOT COVERED BY WARRANTY**

IF YOU ARE IN ANY DOUBT PLEASE CONTACT US




DCWL SERIES (STD AND OPTION 7 CABLES)



CONNECTION DETAILS

6-18V Supply	
RED	6-18V d.c
BLUE	Supply Com. (0V)
GREEN	Output Low
YELLOW	Output High
SHIELD	Instrument Ground



LOAD IMPEDANCE : 2k (min.) Ohms

ISOLATION : 1kV input to output

PHASING : Output high positive with respect to output low for outward stroke.

SUPPLY : Smooth d.c. voltage 100mA max.

OUTPUT : +/- 2.2V nom. (See Calibration Certificate)
(RDP Calibration Supply 15V)

**NOTE : INCORRECT CONNECTION MAY CAUSE IRREPARABLE DAMAGE
CONTACT OUR SALES DEPARTMENT IF YOU REQUIRE ASSISTANCE**

RDP U.K.
Tel 01902 457512
Fax 01902 452000



**MADE IN THE
UNITED KINGDOM**

Doc. Ref. WDUK1950
ISSUE 2 - 16 OCT 2019

RDP U.S.A.
Tel 610 469 0850
Fax 610 469 0852